



# TECHNICAL

## BULLETIN

### FRONT COIL SPRINGS

*Mounting Instructions*

***Ford C-Max, Focus II | Mazda 3 | Volvo C30, C70 II, S40 II, V50***

When replacing front coil springs on the above vehicles, it is important to make sure the top spring plate is correctly lined up with the shock absorber.

**After locating the top pin (see diagram), position the strut top mount so that the top pin aligns with the bottom pin.**

Failure to align the top and bottom pins will cause the spring to bend and rub against the chassis

